Texture Spray

# **Durex**. Texture Spray

## Lightweight Texture Ceiling Plaster Finish

### **Description** Durex<sup>®</sup> Texture Spray is a lightweight economical texturing plaster finish for ceilings.

- Uses To provide an aesthetically pleasing stipple finish over primed drywall and gypsum plaster ceilings and other primed substrates. Primarily intended for residential construction.
  - Versatile texturing product
    - Economical

Features

- Only add potable water for mixing
- Excellent adhesion over a wide number of substrates

#### TECHNICAL DATA

PHYSICAL PROPERTIES	
Product Type	Perlite/calcium carbonate base texturing product
Appearance	White fine powder aggregates
Toxicity	Classified as dust
Bulk Density	1290 kg/m³ (80 ft³)
Pot Life	24 hrs- 36 hrs
Mixing Ratio	1 bag Durex <sup>®</sup> Texture Spray 40 lbs, 18 litres (4 gallons) water
Coverage	Coverage will vary according to texture selection and texturing method used
Average Coverage	16.5 to 27.8 m <sup>2</sup> at 3.2 mm (180 to 300 ft <sup>2</sup> ) per bag
Substrate Requirement	Durex <sup>®</sup> Ceiling Coat (cured), primed drywall, primed plaster surfaces
Packaging	Durex <sup>®</sup> Texture Spray is available in 18.1 kg. (40 lbs) bags and in 11.3 kg (25 lbs) bags.
Storage	Store Durex <sup>®</sup> Texture Spray in a dry, vented, waterproof location, stacked off the ground with ambient temperatures above 5°C (41°F). Keep materials dry, protected from rapid temperature changes, dampness and moisture and away from direct sunlight. <b>KEEP FROM FREEZING</b> .
Mixing Procedure	Discard all materials which have begun to harden. Mix Durex <sup>®</sup> Texture Spray with clean potable water. Mix 1 bag (40 lbs) of Durex <sup>®</sup> Texture Spray with 18 litres (4 gal) of water. Using clean equipment, sift contents of bag into the water; mix until a creamy lump-free consistency is achieved. Do not overmix. Let stand for 10 to 15 minutes. Re-temper and use. <b>DO NOT SUBSTITUTE NOR COMPENSATE DUREX<sup>®</sup> TEXTURE SPRAY WITH ADDITIVES.</b>
Application	Substrate must be dry, solid and sound, free of weak and powdery surfaces, oil, grease-releasing agents and other deleterious materials detrimental to a positive bond. (Consult Durabond Products Limited for questionable surfaces). For drywall and gypsum plaster ceilings, prime all surfaces to be textured with Durex <sup>®</sup> Drywall Primer and allow to dry for a minimum of 24 hours before applying Durex <sup>®</sup> Texture Spray. For concrete ceilings, treat all surfaces with Durex <sup>®</sup> Ceiling Coat and allow to cure for a minimum of 24 hours before applying Durex <sup>®</sup> Texture Spray. Heavier textures can be achieved by applying Durex <sup>®</sup> Texture Spray in a series of two (2) or more coats, allowing each coat to dry between coats for a minimum of two hours. Do not apply more than three (3) coats in any one day period.
Limitations	Durex <sup>®</sup> Texture Spray is not recommended for use: In interior high-humidity areas nor for exterior applications When ambient, surface and materials temperatures are below 5°C (41°F) For wall applications
Clean-up	Clean all tools promptly after each use with clean water. Do not allow mixes to dry on tools.
Health and Safety	For information and advice on the safe handling, storage and disposal of chemical products, refer to the most recent MSDS sheet containing physical, environmental, toxic and other safety/materials handling data. For industrial use only. Keep out of reach of children.

0921

Warranty	Durabond warrants this product is free of manufacturing defects, and will replace at no charge, provided it has been applied within 12 months of purchase, it has been installed for uses suitable for this product and in accordance with the manufacturer's instructions.
Technical Services	Technical support is available upon request at info@durabond.com. For the latest version of this data sheet, please visit our website at www.durabond.com, call toll free at 1-877-DURABOND (387-2266) or speak with your Durabond Products Ltd. sales representative.

#### **UR**a $\overline{\mathsf{D}}$ Ň

 HEAD OFFICE

 55 Underwriters Road

 Scarborough, ON
 M1R 384

 T
 416.759.4474
 F
 416.759.4470

 MISSISSAUGA
 EDMONTON

 6178 Netherhart Road
 14345 120<sup>th</sup> Avenue

 Mississauga, ON
 LST 187

 F 905.565.9283
 F 905.565.9365

 T 780.451.6364
 F 780.453.9056